



# LE/ESSE 2220 Algorithmic and Computational Methods

## Lab 5: Ultrasonic Distance Measurement and Data Logging

(Fall 2025-2026)

Z. ARJMANDI (ZARARJ@YORKU.CA)

---

YORK 

# Review

# Data Logging + Handling

## ➤ Common time Library Commands

Command	Description	Example
time.time()	Returns current time in seconds since epoch ( <b>Unix time</b> )	t = time.time()
time.sleep(seconds)	Pauses the program for given seconds	time.sleep(1)
time.strftime(format)	Formats current time as a string ( <b>String From Time</b> )	time.strftime("%H:%M:%S") → "14:25:03"
time.localtime()	Returns current local time as a struct	time.localtime()
time.ctime()	Returns readable string of current time	time.ctime() → "Thu Oct 9 14:25:03 2025"
time.perf_counter()	High-precision timer for performance measurement	start = time.perf_counter()
time.gmtime()	Returns UTC time as a struct	time.gmtime()

```
import time

# Get current Unix time
t = time.time()
print("Unix time:", t)
```

```
Unix time: 1739088302.451927
```

# Data Logging + Handling

## ➤ Useful txt Commands

Command	Description	Example
<code>open(filename, mode)</code>	Opens a file; returns a file object	<code>f = open("data.txt", "w")</code>
<code>"w"</code>	Write mode – creates or overwrites file	<code>f = open("data.txt", "w")</code>
<code>"a"</code>	Append mode – adds data to the end of the file	<code>f = open("data.txt", "a")</code>
<code>"r"</code>	Read mode – opens existing file for reading	<code>f = open("data.txt", "r")</code>
<code>f.write(string)</code>	Writes a string to the file	<code>f.write("Hello\n")</code>
<code>f.writelines(list)</code>	Writes multiple lines from a list	<code>f.writelines(["A\n", "B\n", "C\n"])</code>
<code>f.read()</code>	Reads the entire file as one string	<code>data = f.read()</code>
<code>f.readline()</code>	Reads one line at a time	<code>line = f.readline()</code>
<code>f.readlines()</code>	Reads all lines into a list	<code>lines = f.readlines()</code>
<code>f.flush()</code>	Forces writing of data to file immediately	<code>f.flush()</code>
<code>f.close()</code>	Closes the file (always do this after writing)	<code>f.close()</code>
<code>with open(...) as f:</code>	Preferred method that auto-closes the file	<code>with open("data.txt", "w") as f:</code>

# Data Logging + Handling

## ➤ Useful csv Library Commands

Command	Description	Example
<code>import csv</code>	Imports the CSV module	<code>import csv</code>
<code>open(filename, mode, newline='')</code>	Opens a CSV file; <code>newline=''</code> prevents blank lines on Windows	<code>f = open("data.csv", "w", newline='')</code>
<code>"w"</code>	Write mode – creates or overwrites the file	<code>open("data.csv", "w", newline='')</code>
<code>"a"</code>	Append mode – adds data to end of file	<code>open("data.csv", "a", newline='')</code>
<code>"r"</code>	Read mode – opens existing CSV file	<code>open("data.csv", "r")</code>
<code>csv.writer(file)</code>	Creates a writer object for writing rows	<code>writer = csv.writer(f)</code>
<code>writer.writerow(list)</code>	Writes one row (as a list)	<code>writer.writerow(["time_s", "distance_cm"])</code>
<code>writer.writerows(list_of_lists)</code>	Writes multiple rows at once	<code>writer.writerows(data)</code>
<code>csv.reader(file)</code>	Creates a reader object for reading rows	<code>reader = csv.reader(f)</code>
<code>next(reader)</code>	Reads or skips the next row (often header)	<code>header = next(reader)</code>
<code>for row in reader:</code>	Iterates through remaining rows	<code>for row in reader: print(row)</code>
<code>list(reader)</code>	Converts all rows to a list of lists	<code>rows = list(reader)</code>
<code>with open(...) as f:</code>	Preferred form – auto-closes file	<code>with open("data.csv", "w", newline='') as f:</code>
<code>delimiter=","</code>	Optional: define a custom separator	<code>csv.reader(f, delimiter=",")</code>
<code>quotechar='\"'</code>	Defines the character used for quoting text	<code>csv.writer(f, quotechar='\"')</code>
<code>f.close()</code>	Closes the file (not needed if using with)	<code>f.close()</code>

# Data Logging + Handling

## ➤ Example 1 – Writing and Reading a TXT File

```
# Example: Logging temperature readings to a text file

temperatures = [21.5, 22.0, 22.3, 22.1, 21.9]

# Write data to TXT file
with open("temperature_log.txt", "w") as f:
    f.write("reading_no\ttemperature_C\n")
    for i, t in enumerate(temperatures):
        f.write(f"{i+1}\t{t}\n")

print("Data written to temperature_log.txt")

# Read data back from TXT file
with open("temperature_log.txt", "r") as f:
    lines = f.readlines()
    print("File contents:")
    for line in lines:
        print(line.strip())
```

reading_no	temperature_C
1	21.5
2	22.0
3	22.3
4	22.1
5	21.9

# Data Logging + Handling

## ➤ Example 2 – Writing and Reading a CSV File

```
# Example: Logging temperature readings to a CSV file
import csv

temperatures = [21.5, 22.0, 22.3, 22.1, 21.9]

# Write data to CSV file
with open("temperature_log.csv", "w", newline="") as f:
    writer = csv.writer(f)
    writer.writerow(["reading_no", "temperature_C"])
    for i, t in enumerate(temperatures):
        writer.writerow([i+1, t])

print("Data written to temperature_log.csv")

# Read data back from CSV file
with open("temperature_log.csv", "r") as f:
    reader = csv.reader(f)
    header = next(reader)
    print("Header:", header)
    for row in reader:
        print(row)
```


```
Header: ['reading_no', 'temperature_C']
['1', '21.5']
['2', '22.0']
['3', '22.3']
['4', '22.1']
['5', '21.9']
```

# Lab 5




# Ultrasonic Ranging

## Lab 5: Ultrasonic Distance Measurement and Data Logging




# Lab 5: Ultrasonic Distance Measurement and Data Logging

## ➤ Build the Circuit



# Lab 5: Ultrasonic Distance Measurement and Data Logging



➤ For more details on this circuit, please refer to Tutorial Chapter 21 (available on E-Class).



The GPIO pins on the Raspberry Pi only tolerate 3.3 V max , more can damage the Pi.  
So, we use resistors to divide 5 V down to about 3.3 V before it reaches the Pi's input pin.

# What Happens Inside the Ultrasonic Module

## ➤ Pin description:




Pin	Type	Function
VCC	Power	Connects to <b>5V</b> (or 3.3V on some boards). Powers the ultrasonic module.
Trig (Trigger)	Input	This is where you send a short <b>10 µs HIGH pulse</b> from your Raspberry Pi. It tells the sensor to send an ultrasonic burst.
Echo	Output	This pin goes <b>HIGH</b> for the duration that the ultrasonic wave travels to the obstacle and back. Your code measures this pulse width to calculate distance.
GND	Ground	Connects to <b>GND</b> of your Raspberry Pi. Completes the circuit.

# What Happens Inside the Ultrasonic Module

- One **transmitter** — it sends ultrasonic pulses (~40 kHz).
- One **receiver** — it listens for the reflected echo.

Step	Event	Echo Pin
Send 10 $\mu$ s Trigger	Module emits sound	Goes HIGH
Waiting for echo	Listening for reflection	Stays HIGH
Echo detected	Wave reflected & received	Goes LOW
MCU measures HIGH duration	→ Time of flight	



$$\text{Distance} = \text{Echo time} \times \text{sound velocity} / 2 .$$

# Lab 5: Steps

## ➤ 1- Test the existing code

- Run UltrasonicRanging.py.
- Confirm the sensor prints distance values correctly in the terminal.

## ➤ 2- Record data in a text file (TXT)

- Modify the code to save each measurement with time and distance.
- Record data for about 60 seconds while moving an object slowly toward and away from the sensor.
- Save as distance\_log.txt.
  - The first column is elapsed time in seconds since the start of recording.
  - The second column is the measured distance in centimeters.
- **Specify in your report** the sampling interval (time between readings) and total duration of the recording.

```
time_s      distance_cm
0.000       50.32
0.100       49.95
0.200       49.80
...
```

## ➤ 3- Record data in a CSV file and visualize

- Use Python's csv module to save the same data in distance\_log.csv.
- Open the CSV file in Excel.
- Insert a Scatter or Line chart with Time (s) on the X-axis and Distance (cm) on the Y-axis.
- Label the chart as **Distance vs Time**.

# Report Format (short, personal, verifiable)

## > Setup

- Attach a **clear photo of your circuit** showing the ultrasonic sensor (HC-SR04 or similar) connected to the Raspberry Pi (with resistors on the Echo pin if used).
- Copy and paste your **final code** (main program)
- Include **meaningful comments** explaining each main part of your code.

## > Observations

- Record the **distance readings** displayed in the terminal while your program runs.
- Open your **distance\_log.txt** file, describe what kind of data is stored there and how it's formatted.
- Open your **distance\_log.csv** file in Excel, insert a **Distance vs Time** plot.
- Include a **screenshot of a portion of the collected data** (both TXT and CSV file).
- **Copy and paste your graph** (Distance vs Time) into the report.
- Clearly **state the sampling interval** (time between readings) and **total recording duration** used.
- Compare the data from the TXT and CSV files, are they identical or slightly different? Why?
- How consistent are the readings when the object is still? What happens when the object moves faster or slower?

## > Analysis

- How does the Echo pin indicate that an ultrasonic pulse has returned?
- Why do we divide the total time by 2 when calculating distance?
- What are two possible causes of inaccurate or noisy distance readings?
- How could you modify your program to reduce these errors (hardware or software changes)?
- If you increase the sampling rate (shorter delay), what effect might it have on data quality or reliability?
- How could you extend this setup to measure speed or detect motion?

# Rubric

## ➤ Circuit Setup – 1 pts

## ➤ Code – 4 pts

- Program runs correctly without errors – 1 pts
- Includes meaningful comments explaining each major section (setup, trigger, echo, data logging) – 1 pt
- Properly logs data in both TXT and CSV files with correct formatting – 2 pt

## ➤ Observations – 3 pts

- Includes terminal readings, TXT file structure, and Excel Distance vs Time plot.
- Answers all questions clearly.

## ➤ Analysis – 2 pts

- Answers all analysis questions clearly.